## Care of ceramic bowls

For our customers using Takara Belmont wash unit, we will guide you on how to care for the ceramic bowl.

This is to advice only for the Ceramic bowl.

CAUTION For cleaning resin parts and metal parts, refer to the Operating Instructions of the wash unit you are using.

## Things to prepare

Soft sponge, soft toothbrush, cream cleanser (cif, etc.)

or

Melamine sponge



## How to care

Apply "cream cleanser" to a "soft sponge" that has been moistened with water and squeezed firmly, and wipe off any dirt. Use a soft toothbrush in places where it is difficult to use sponge.

If the dirt cannot be removed, rub it with a "melamine sponge" moistened with water.

Do not use the following: Surface may be scratched.

- Metal scrubbing brush and hard brush
- Cleanser containing alumina-based minerals



Do not use it on resin parts such as tap and thermostatic control knob, or on metal parts that have been surface-coated such as neck parts. It may be scratched.

