


Model

A K - S 2 3 S A K - S 2 3 S F

P

Assembly Instructions







<Before Assembling the Product>

Check the parts supplied with the product.

Prepare a No.2 Phillips-head screwdriver for assembling.





M5 x 15 cap bolt (with spring washer): 2 pieces

Joint the upper main unit and the stand pole with the supplied 2 screws temporarily.

Tighten the screws after the two parts are correctly aligned.

*Use the supplied L-shaped wrench.

*In order to align the


stand pole and the upper main unit easily,

these holes are elliptically shaped.





Never release your hands from the shaft throughout the operation of step. Doing so may cause an impact to the root of the shaft, resulting in a damage of the product.


Dropping the shaft may cause a strong impact that can result in a damage of the product.



Do not apply pressure onto the shaft. *Doing so may cause a damage of the product.









Hold the shaft firmly with your hands throughout the procedure of step. Never release your hands from the shaft until you complete tightening the screws.

• Raising and fixing the shaft.


Loosen the screws on the shaft with the L-shaped wrench, raise the shaft up, and tighten with the lock screw. *Never release your hands from the shaft until you complete this procedure.






Set the upper main unit cover. *Pay attention to the positions of the latches.

screw. *Use the Phillips-head screwdriver.



Checking of Operations



Process

After completion of the installation, check the following No. $1 \sim 3$. *3 is only for the specification with Fan.

①Check the initial status

•Confirm that all lamps illuminate for one second after turning on the power switch. Then only the operating mode lamps (4 lamps) will blink.

2 Check the operation

•Press the MANUAL button.

→ Press Start/Stop button.
Confirm that the ring rotates and heater works properly
Pilot lamp (blue) blinks.
<*CAUTION >
Heater starts glowing after the ring rotates approx. 360 degrees.

③Check the operation of fan (only for specification with fan)

•While doing the check No. (ring is rotating), press the FAN button once. *After pressing theFAN button, fan starts rotating and the lamp of the FAN button illuminates.

After confirming the above, the installation is completed.